



PAINT CORROSION CABINET

CODE: 10020

Used to measure the corrosion of painted panels under humidity conditions within a definite temperature range.

Inner chamber is made of Stainless steel, In built reservoir, to heat the cabinet through water with air circulating fan to maintain a uniform temperature inside the cabinet.

Confirming to **IS:101**.

- * Cabinet is supplied with panel Rack.
- * Digital temperature controller cum indicator.
- * Working temp. Range: 42 to 48C.
- * Operation on 230V, single phase.
- * Water tank volume : approx. 15ltr.



MODELS:

with Rack for 6 panels.	CODE:10020-00
with Rack for 24 panels.	10020-01
Flat box type cabinet for 60 panels.	10020-02
Third party Calibration certification	10020-05

ACCESSORIES

Humidity Indicator	10020-03
Programmable recorder with PC interface	10020-04



Culture Instruments India LLP

Works: D-428, 10th MAIN ROAD, PEENYA 2nd STAGE, P.I.A, BANGALORE - 560 058. (INDIA)

Office:

#37, III MAIN ROAD, VYALIKAVALL, BANGALORE - 560 003. (INDIA)

PH: 91 - 080 - 23349239 / 23449007 / 09886780513

Email: cultureinstruments@gmail.com / sales@technoinstruments.co.in

Website: www.technoinstruments.co.in

